

Technical Information HARO Flexible Glue

ID No. 410 563 410 565

Product Single-component parquet adhesive for multi-layer parquet, DISANO, CELENIO, Hamberger

boards, strip parquet without finish and solid beech/maple boards of at least 20 mm thickness and up to 140 mm width and other solid wood floorboards of at least 16 mm thickness and up to 250

Product properties - Ready to use

Solvent-freeVery low emission

- Suitable for use with underfloor heating

- Elastically curing

- Water-free

Scope of application Solvent-free single-component adhesive for elastic glue-down installation of parquet, CELENIO

and DISANO Classic/Classic Aqua/Smart Aqua/Saphir design floors on absorbent and non-absorbent subfloors with subfloors levelled with standard filler (with low plastic coating, ask

Areas of application
- 2- and 3-layer parquet

- design floors DISANO Classic/Classic Aqua/Smart Aqua/Saphir design floors/Life Aqua

- Celenio wood floors

- Strip parquet without finish

- Solid beech/maple floorboards of at least 20 mm thickness and up to 140 mm width; other solid

wood floorboards of at least 16 mm thickness and up to 250 mm width

Technical data Raw material basis: Silane-modified polymer

Setting time: None

Open time: Approx. 40 minutes
Setting time Approx. 24 - 48 hours

Storage time: 18 months at room temperature

Storage temperature: Not sensitive to frost

GISCODE: RS10

EMICODE according to GEV: EC1 PLUS R

Subfloor The subfloor as well as indoor climate conditions must comply with the requirements of DIN

18356. Subfloors must be completely dry, solid, level, free of cracks, dirt and substances inhibiting the adhesion. Calcium sulphate screeds must always be mechanically pretreated and well vacuumed in accordance with the manufacturer's instructions and currently applicable standards and information sheets. The parquet can be flexibly glued down directly using HARO flexible glue if the screed is dust-free. If a precoat is required, HARO Primer can be used on cement and calcium sulphate bound screed. HARO flexible glue is not suitable for flexible use on mastic

asphalt floors without first consulting the Technical Service department.

Instructions Apply HARO Flexible Glue (without thinning) evenly to the subfloor using an appropriate spreader

from the HARO accessories range (type of spreader depends on floor covering). Ensure adequate adhesive transfer to the underside of the board. Always leave a gap of 10-15 mm to the wall. Remove adhesive stains on the floor covering immediately. Clean tools immediately after use. Avoid walking on parquet surfaces during installation and in the first 24 hours after installation.

Important notes Do not use if floor temperature is below +15°C and ambient temperature is below +18°C; indoor

humidity preferably between 40% and 65% and at most 75%. All data is based on a temperature of around 20°C and relative humidity of 65%. Avoid adhesive in the board joints as this might cause undesired interaction with subsequent surface finishing products. All information is based on tests and many years of practical experience and refers to use under standard conditions. Different site conditions beyond our control and the variety of materials used exclude any claims for compensation based on this information. We therefore recommend adequate patch tests prior to application. The laying instructions of the floor covering manufacturers and the currently

applicable standards and information leaflets must be observed.



This technical information is for your guidance and support and is based on our most up-to-date knowledge. It makes no representation or warranty, express or implied, as to any specific properties of the described product within the meaning of the statutory warranty regulations.